

PLANTAGEN®

VISBY RELAX CHAIR
563053



PLANTAGEN®





PLANTAGEN®

POLYPROPYLENE, 600D polyester
To clean the product, wipe with mild soap and water, dry thoroughly. Do not wash it with water.
Do not use bleach, acid, solvents or abrasive cleaners on this item. If you use furniture polish, spot check a small area first.
Wipe it quickly when the chair is wet.

Steel
If the product is not to be used for long periods or during the winter, store in a dry location or under a suitable cover.
Before putting into storage, insure the item is clean and dry. In case of heavy rain, transport inside the building or cover it appropriately.