









KINSLEY KITCHEN BASIC
558807




 A= 1 pc	 B= 1 pc	 C= 1 pc	 D= 2 pcs	 E= 2 pcs  F= 2 pcs	 G= 1 pc	 H= 1 pc


Screws 6x40 mm  T1= 12 pcs	Screws 4x20 mm  T2= 6 pcs
Allen key 4mm  T3= 1 pc	




STEP
1




STEP
2




STEP
3



STEP
4



STEP
5



FINISHED

Acacia:

Daily exposure to intense ultraviolet radiation from sunlight will deteriorate the wood material over time.
Use a furniture cover of good quality to extend the life of your furniture.
During winter time, the best is to store in a dry and well-ventilated place.
Clean with damp, soft cloth and soap that does not contain detergents.

Good to know:

Sun exposure and weather conditions affect all outdoor materials over time, and color changes are a natural part of the product's aging process. To avoid visible color differences, surfaces should be exposed evenly, especially on tables with extension leaves or where parts of the surface are covered for extended periods.